



Fe 4	Anglaise	Rahmenhöhe (cm)			
		48	52	56	60

A	Oberrohrlänge (mm)	549	582	587	591
B	Sitzrohrlänge (mm)	480	520	560	600
C	Kettenstrebenlänge (mm)	470	470	470	470
D	Front Center (mm)	635	640	650	650
E	Radstand (mm)	1094	1099	1109	1109
F	Steuerrohrwinkel (Grad)	70°	71°	71°	71°
G	Sitzwinkel (Grad)	73,5°	72,5°	72,5°	72,5°
H	Reach (mm)	400	413	414	407
I	Stack (mm)	581	585	613	632
J	Tretlagerabsenkung (mm)	78	78	78	78
K	Tretlagerhöhe (mm)	282	282	282	282
	Einstiegshöhe (mm)	555	580	581	581

Fe 4	Swiss Curve	Rahmenhöhe (cm)	
		49	54

A	Oberrohrlänge (mm)	558	575
B	Sitzrohrlänge (mm)	490	540
C	Kettenstrebenlänge (mm)	483	483
D	Front Center (mm)	640	650
E	Radstand (mm)	1112	1122
F	Steuerrohrwinkel (Grad)	69°	69°
G	Sitzwinkel (Grad)	71,5°	71,5°
H	Reach (mm)	386	395
I	Stack (mm)	604	605
J	Tretlagerabsenkung (mm)	78	78
K	Tretlagerhöhe (mm)	282	282
	Einstiegshöhe (mm)	512	513

Fe 4	Diamant	Rahmenhöhe (cm)					
		50	54	58	62	66	70

A	Oberrohrlänge (mm)	551	580	589	603	630	643
B	Sitzrohrlänge (mm)	500	540	580	620	660	700
C	Kettenstrebenlänge (mm)	470	470	470	470	482	482
D	Front Center (mm)	635	640	648	658	664	670
E	Radstand (mm)	1094	1099	1107	1117	1136	1141
F	Steuerrohrwinkel (Grad)	70°	71°	71°	71°	72°	72,5°
G	Sitzwinkel (Grad)	73,5°	72,5°	72,5°	72,5°	72°	72°
H	Reach (mm)	399	413	412	415	426	427
I	Stack (mm)	581	584	613	632	655	685
J	Tretlagerabsenkung (mm)	78	78	78	78	78	78
K	Tretlagerhöhe (mm)	282	282	282	282	282	282
	Einstiegshöhe (mm)	741	776	814	851	888	925

**CONTOURA**